



DJI Phantom 2 Vision Motor Replacement

Use this guide to replace the motors in your DJI Phantom 2 Vision.

Written By: Sam Lionheart



INTRODUCTION

This DJI Phantom 2 Vision upgrade guide shows how to remove the cover and motors, and replace the motors with new or upgraded ones.

[video: <http://youtu.be/pwD-Vtc3ql8>]



TOOLS:

- [Soldering Station](#) (1)
 - [1.5mm Hex Screwdriver](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
 - [12mm Wrench](#) (1)
-

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 08:45:20 PM.